SNAPSHOOT
ENGINEERED FOR A SAFER TOMORROW

현장을 이해하고, 필요한 솔루션을 연결합니다.

산업안전 · 추락방지 시스템
산업용 소재 · 건축자재
제품 제안부터 공급·시공·설치·교육까지



COMPANY INFORMATION

스냅슛 (SNAPSHOOT)

ADDRESS (15431) 경기도 안산시 단원구 풍전로 37-9 트리플렉스 301동 118호
TEL 0507-1374-9229
FAX 0504-481-6749
E-MAIL bkkim@snapshoot.co.kr

TECHNICAL DOCUMENTS

인증서 · 데이터시트 · 기술자료

제품의 규격과 성능, 인증 및 적용 조건을 확인하기 위한 자료입니다.

ABOUT SNAPSHOOT

제품 공급을 넘어, 현장에 맞는 해결책으로

스냅슛은 산업현장의 작업 환경과 요구 조건을 바탕으로
적합한 제품과 시스템을 제안합니다. 현장 실사를 통해 설치 조건을 확인하고,
공급부터 시공·설치 및 사용 교육까지 필요한 과정을 함께합니다.

추락방지 시스템

안전대부착설비 · 수평·수직 라이프라인
레일 시스템 · 리지드 포스트

밀폐공간 진입·구조 솔루션

데빗암 · 삼각대 · 구조용 윈치
윈치 안전블록 · 구조장비

산업안전 보호구

전신형 안전대 · 랜야드 · 안전블록
작업 환경에 맞춘 개인보호구

산업용 소재·건축자재

산업용 테이프 · 접착제 · 기능성 소재
구조용 스크류 · 목조건축 자재

SNAPSHOOT
ENGINEERED FOR A SAFER TOMORROW

홈페이지 바로가기 →
문서 라이브러리 바로가기 →
시공사례 바로가기 →
문의하기 →

본 페이지는 스냅슛의 자료 제공 안내용 표지입니다. 첨부된 인증서 및 기술자료의 발행 주체, 인증 대상과 적용 범위는 해당 원문을 기준으로 확인해 주세요.

colitag™ Quality Control Kit



Pictured: E. coli



Pictured: E. coli pellet

Introduction

The NEOGEN® Colitag™ Quality Control (QC) kit allows for a verification of the Colitag media and the expected results. The following organisms are included in the kit, and each one provides a unique result.

E. coli: Positive yellow color change with fluorescence; verified as *E. coli* coliform by Colitag.

E. aerogenes: Positive yellow color change and no fluorescence; verified as Total coliform by Colitag.

P. aeruginosa: No yellow color change and no fluorescence; verified as a negative control by Colitag.

Materials avaliable

S2-COLITAG-QCKIT — Colitag QC kit
NEOGEN item 9857 — Colitag Comparator, 100 mL
NEOGEN item 9850 — Colitag P/A Water Test Kit (pack of 20)
NEOGEN item 9851 — Colitag P/A Water Test Kit (pack of 100)
NEOGEN item 9849 — Colitag P/A Water Test Kit (pack of 200)

Storage conditions

Freezer (-20 to -10°C)

Instructions for use

1. Remove the sample vial from the freezer. Allow the unopened sample vial to equilibrate to room temperature (15–30°C). This will take approximately 10–15 minutes.
2. Once at room temperature, open the vial by removing the cap and stopper.
3. Add 100 mL of sterile deionized water to the sample vessel.
4. Add the microorganism pellet to the sample vessel. Allow the pellet to dissolve completely. After the pellet has dissolved, gently mix to homogenize the sample.
5. Add Colitag media to a 100 mL water sample containing the dissolved microorganism pellet suspension.

6. Incubate the sample for 16–48 hours at 35 ± 0.5°C. For reading between 16 and 22 hours, place the water sample vessel into a 44.5°C water bath for 7–10 minutes before incubation.
7. After incubation, visually check each sample for a yellow color change. If the sample is less yellow than the Colitag comparator (P/A), the sample is negative for total coliforms. If the sample is equal to or greater yellow than the Colitag comparator (P/A), the sample is positive for total coliforms. Check for fluorescence using a longwave (365 nm) UV lamp. If the yellow sample fluoresces, the sample is positive for *E. coli* bacteria. If the yellow sample does not fluoresce, the sample is negative for *E. coli* bacteria.
8. Dispose of all material in accordance with local biohazardous waste disposal requirements.

Disclaimers

Information provided is based on validation procedures that NEOGEN performed in NEOGEN laboratories. Deviation from procedures is possible but should be discussed with NEOGEN Technical Services.

© NEOGEN Corporation, 2020. NEOGEN is a registered trademark and Colitag is a trademark of NEOGEN Corporation, Lansing MI 48912 U.S.
All other brand and product names are trademarks or registered trademarks of their respective companies.