SNAPSHOOT
ENGINEERED FOR A SAFER TOMORROW

현장을 이해하고, 필요한 솔루션을 연결합니다.

산업안전 · 추락방지 시스템
산업용 소재 · 건축자재
제품 제안부터 공급·시공·설치·교육까지



COMPANY INFORMATION

스냅슛 (SNAPSHOOT)

ADDRESS (15431) 경기도 안산시 단원구 풍전로 37-9 트리플렉스 301동 118호
TEL 0507-1374-9229
FAX 0504-481-6749
E-MAIL bkkim@snapshoot.co.kr

TECHNICAL DOCUMENTS

인증서 · 데이터시트 · 기술자료

제품의 규격과 성능, 인증 및 적용 조건을 확인하기 위한 자료입니다.

ABOUT SNAPSHOOT

제품 공급을 넘어, 현장에 맞는 해결책으로

스냅슛은 산업현장의 작업 환경과 요구 조건을 바탕으로
적합한 제품과 시스템을 제안합니다. 현장 실사를 통해 설치 조건을 확인하고,
공급부터 시공·설치 및 사용 교육까지 필요한 과정을 함께합니다.

추락방지 시스템

안전대부착설비 · 수평·수직 라이프라인
레일 시스템 · 리지드 포스트

밀폐공간 진입·구조 솔루션

데빗암 · 삼각대 · 구조용 윈치
윈치 안전블록 · 구조장비

산업안전 보호구

전신형 안전대 · 랜야드 · 안전블록
작업 환경에 맞춘 개인보호구

산업용 소재·건축자재

산업용 테이프 · 접착제 · 기능성 소재
구조용 스크류 · 목조건축 자재


SNAPSHOOT
ENGINEERED FOR A SAFER TOMORROW

홈페이지 바로가기 →
문서 라이브러리 바로가기 →
시공사례 바로가기 →
문의하기 →

본 페이지는 스냅슛의 자료 제공 안내용 표지입니다. 첨부된 인증서 및 기술자료의 발행 주체, 인증 대상과 적용 범위는 해당 원문을 기준으로 확인해 주세요.

AccuPoint Advanced — Getting started with RFID


INSTALLING DATA MANAGER SOFTWARE



To install Data Manager, run **setup.exe** from the installation CD. Be sure to check the **ENABLE RFID** box.

1 CREATE AND SYNC TEST PLAN

1. Use Data Manager to create a test plan for **Groups** and **Sites**.
   a. **Groups** are organized on the left, **Sites** are organized on the right.
   b. **Descriptions** can be added to each site.
   c. Select the **Water** column to indicate a water sampler should be used during testing.
   d. **Fail** threshold level can be set for each site.
   e. **Marginal** threshold level can be set for each site.
   f. **Mandatory site** can be identified.
   g. **Select** or **Deselect** a site to be part of the synced plan.
   h. Click on the **trash can** to delete a group or site.
2. Power on AccuPoint Advanced reader to the main screen and select **Sync to reader**.



NEOGEN®

USA/Canada
800/234-5333 or 517/372-9200
foodsafety@neogen.com

Neogen Europe
+ 44 (0) 1292 525 640
0800 182 7721
info_de@neogeneurope.com

Neogen Latinoamerica
+ 52 (55) 5254-8235, + 52 (55) 5203-1198
informacion@neogenlac.com

Neogen do Brasil
+ 55 19 3935.3727
info@neogendobrasil.com.br

AccuPoint Advanced Getting started with RFID

2 PROGRAM RFID TAGS



3. With the AccuPoint Advanced reader connected via USB, select **Program RFID Tags**.
4. Hold the antenna (on the back of the AccuPoint Advanced reader) near an RFID tag
   to assign the first group of sites.
5. Repeat the process for each group until all the tags have been assigned.
6. When all tags are assigned, select the icon on the lower left of the display to accept the mapping.

3 UPLOAD RFID MAP



7. Reconnect AccuPoint Advanced reader to USB.
8. Select **Upload RFID Map**.

NOTE: An icon will appear beside the Group when a RFID tag has been assigned. Use the **Clear RFID Map** command remove all RFID tags assigned to Groups.

PROGRAM MODE ICONS:

- Select this to accept remapping of a RFID tag.
- Select this to cancel the remapping of a RFID tag.
- Indicates a group does not have a RFID tag assignment.
- Indicates a group has a RFID tag assignment.
- Shows when AccuPoint Advanced Reader is in RFID Program Mode.
- Select to exit RFID Program Mode.

NEOGEN®

USA/Canada
800/234-5333 or 517/372-9200
foodsafety@neogen.com

Neogen Europe
+ 44 (0) 1292 525 640
0800 182 7721
info_de@neogeneurope.com

Neogen Latinoamerica
+ 52 (55) 5254-8235, + 52 (55) 5203-1198
informacion@neogenlac.com

Neogen do Brasil
+ 55 19 3935.3727
info@neogendobrasil.com.br

1235A-0315